

Instruction Sheet – Honda Accord Rear Toe Arm

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

READ BEFORE INSTALLING

If this arm is being installed as a direct replacement of the stock arm adjust length of arm to 9-7/8 inches (251mm) measured at center of inner and outer bushing holes. After installation recheck length and tighten all bolts and both locknuts. Adjust toe using stock toe adjuster cam.

If this arm is being used in conjunction with the Honda Accord Adjustable Camber Arm and/or Honda Accord Adjustable Lateral Arm refer to instruction sheet for the Honda Accord Full Arm Set.

Printed in U.S.A. • Form No. 985551GEN • Rev. 10/14

Instruction Sheet – Honda Accord Rear Toe Arm

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

READ BEFORE INSTALLING

If this arm is being installed as a direct replacement of the stock arm adjust length of arm to 9-7/8 inches (251mm) measured at center of inner and outer bushing holes. After installation recheck length and tighten all bolts and both locknuts. Adjust toe using stock toe adjuster cam.

If this arm is being used in conjunction with the Honda Accord Adjustable Camber Arm and/or Honda Accord Adjustable Lateral Arm refer to instruction sheet for the Honda Accord Full Arm Set.

Printed in U.S.A. • Form No. 985551GEN • Rev. 10/14

Instruction Sheet – Honda Accord Rear Toe Arm

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

READ BEFORE INSTALLING

If this arm is being installed as a direct replacement of the stock arm adjust length of arm to 9-7/8 inches (251mm) measured at center of inner and outer bushing holes. After installation recheck length and tighten all bolts and both locknuts. Adjust toe using stock toe adjuster cam.

If this arm is being used in conjunction with the Honda Accord Adjustable Camber Arm and/or Honda Accord Adjustable Lateral Arm refer to instruction sheet for the Honda Accord Full Arm Set.

Printed in U.S.A. • Form No. 985551GEN • Rev. 10/14

Instruction Sheet – Honda Accord Rear Toe Arm

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

READ BEFORE INSTALLING

If this arm is being installed as a direct replacement of the stock arm adjust length of arm to 9-7/8 inches (251mm) measured at center of inner and outer bushing holes. After installation recheck length and tighten all bolts and both locknuts. Adjust toe using stock toe adjuster cam.

If this arm is being used in conjunction with the Honda Accord Adjustable Camber Arm and/or Honda Accord Adjustable Lateral Arm refer to instruction sheet for the Honda Accord Full Arm Set.

Printed in U.S.A. • Form No. 985551GEN • Rev. 10/14