

Instruction Sheet – Honda Accord Rear Lateral Control Arm

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

READ BEFORE INSTALLING

If this arm is being installed as a direct replacement of the stock arm adjust length of arm to 15 inches (394mm) from center of saddle hole to center of bushing hole. After installation recheck length and tighten all bolts and both locknuts. Use supplied nut and stock bolt to attach brake cable to bracket.

If this arm is being used in conjunction with the Honda Accord Adjustable Camber Arm and/or Honda Accord Adjustable Toe Arm refer to instruction sheet for the Honda Accord Full Arm Set.

Printed in U.S.A. • Form No. 985501GEN • Rev. 10/14

Instruction Sheet – Honda Accord Rear Lateral Control Arm

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

READ BEFORE INSTALLING

If this arm is being installed as a direct replacement of the stock arm adjust length of arm to 15 inches (394mm) from center of saddle hole to center of bushing hole. After installation recheck length and tighten all bolts and both locknuts. Use supplied nut and stock bolt to attach brake cable to bracket.

If this arm is being used in conjunction with the Honda Accord Adjustable Camber Arm and/or Honda Accord Adjustable Toe Arm refer to instruction sheet for the Honda Accord Full Arm Set.

Printed in U.S.A. • Form No. 985501GEN • Rev. 10/14

Instruction Sheet – Honda Accord Rear Lateral Control Arm

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

READ BEFORE INSTALLING

If this arm is being installed as a direct replacement of the stock arm adjust length of arm to 15 inches (394mm) from center of saddle hole to center of bushing hole. After installation recheck length and tighten all bolts and both locknuts. Use supplied nut and stock bolt to attach brake cable to bracket.

If this arm is being used in conjunction with the Honda Accord Adjustable Camber Arm and/or Honda Accord Adjustable Toe Arm refer to instruction sheet for the Honda Accord Full Arm Set.

Printed in U.S.A. • Form No. 985501GEN • Rev. 10/14

Instruction Sheet – Honda Accord Rear Lateral Control Arm

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

READ BEFORE INSTALLING

If this arm is being installed as a direct replacement of the stock arm adjust length of arm to 15 inches (394mm) from center of saddle hole to center of bushing hole. After installation recheck length and tighten all bolts and both locknuts. Use supplied nut and stock bolt to attach brake cable to bracket.

If this arm is being used in conjunction with the Honda Accord Adjustable Camber Arm and/or Honda Accord Adjustable Toe Arm refer to instruction sheet for the Honda Accord Full Arm Set.

Printed in U.S.A. • Form No. 985501GEN • Rev. 10/14